



Monteringsvejledning for friskluftsystem (tilslutning bagud)	<b>DK</b>
Assembly instructions for combustion air system (rear connection)	<b>GB</b>
Einbauanleitung für das Verbrennungsluftsystem (Anschluss hinten)	<b>DE</b>
Monteringsanvisning för förbränningsluftssystem (anslutning baktill)	<b>SE</b>
Monteringsveiledning for forbrenningsluftsystem (tilkobling fra baksiden)	<b>NO</b>
Montage-instructies voor het verbrandingsluchtstysteem (aansluiting aan de achterzijde)	<b>NL</b>
Guide d'installation du système à air de combustion (raccordement arrière)	<b>FR</b>
Istruzioni di montaggio del kit d'aria di combustione (collegamento posteriore)	<b>IT</b>
Instrucciones de montaje de aire de combustión (conexión por detrás)	<b>ES</b>





09.09.2021 / 53-1190  
[www.hwam.com](http://www.hwam.com)








**hwam**  
 intelligent heat





**HWAM 4110 + 4120**





**HWAM 4130+4140+4150+4160**

